



**NOTES:**

- 1) INSTALL J1 & J3 FOR NORMALLY UNMUTED OPERATION. IN THIS MODE A CONTACT CLOSURE SUPPLIED ACROSS THE MUTE 1 TERMINALS (AVAILABLE AT THE REAR OF THE AMPLIFIER) WILL MUTE THE OUTPUT.
- 2) REMOVE J1 & J3, AND INSTALL J2 FOR NORMALLY MUTED OPERATION. IN THIS MODE, THE OUTPUT IS NORMALLY MUTED AND WILL UNMUTE BY SUPPLYING A CONTACT CLOSURE AT THE MUTE 1 TERMINAL AVAILABLE AT THE REAR OF THE AMPLIFIER.
- 3) INSTALL J1 & J4 FOR NORMALLY UNMUTED OPERATION IN THIS MODE A CONTACT CLOSURE SUPPLIED ACROSS THE MUTE 2 TERMINALS (AVAILABLE AT THE REAR OF THE AMPLIFIER) WILL MUTE THE OUTPUT.
- 4) INSTALL J5 FOR PHANTOM POWER OPERATION. JUMPER SUPPLIED WITH MODULE MOUNTING SCREWS.

DATE 3/89		TITLE		UNIVERSITY SOUND INC	
DRWN KLK		ELECTRICAL		SIZE	DRAWING #
ENGR KLK		SCHEMATIC		B	600-9505-00
APRVD		CRH-31		SHEET	1 OF 1
REV	ECN #	DATE	TOLERANCE		

UNIVERSITY SOUND INC	DATE	REV	REV	REV	REV
8 552-5505-00	18-MAR	1	1	1	1
1					