
# Electro-Voice



## SL15-MB

## Adjustable Mounting Bracket Kit

- · Easily mounted
- Ceiling suspended or wall mounted
- · Adjustable angle positioning
- · Attractive black crinkled finish

#### Description

The SL15-MB adjustable mounting bracket kit is designed to permanently attach the Electro-Voice SL15-2H either suspended from the ceiling for better isolation or mounted on the wall.

The SL15-MB allows the speaker to adjust to different angles about its mounting center, after it has been either suspended from the ceiling or mounted to the wall. Locking screws are included to secure the system's final position. The SL15-MB allows the SL15-2H to be mounted at 0°, +10° or +20° to achieve the desired sound coverage.

The SL15-MB supports the SL15-2H with four 1/4-20 hex-head screws which fasten the bracket to threaded inserts preinstalled in the speaker cabinet. A set of mounting screws and shoulder washers are included with the SL15-MB kit.

Three adjustment holes allow any of three positions (0°,+10° and +20°) to be selected and locked. Aligning the adjustment screw with the hole position, sets the bracket at 0°, the next hole up is the  $+10^{\circ}$  setting and the highest hole is  $+20^{\circ}$ .

#### Mounting

To access the mounting inserts on the SL15-2H, remove the desired cap plugs depending on which mounting position is used.

For Wall Mounting: (See Figure 1)

- Mount the SL15-MB bracket to the wall.
  - Caution: Due to the weight of the SL15-2H enclosure, it is imperative that the SL15-MB bracket be secured to the wall. The choice of fasteners (not provided with bracket kit) will be determined by the material and construction of the wall. It is the responsibility of the Installer to ensure the integrity of the mounting surface.
- Install provided shoulder washer and screw in the easy mounting screw insert position about 3/4 of the way in. Also install the shoulder washer in the appropriate adjustment insert hole.

(See Wall Mounting Figure 1)

 Set the SL15-2H on the mounting bracket by sliding the mounting position screws into the easy mounting slot and guiding it into the installed posi-

- tion, which is all the way forward. Make sure the bracket is placed between the screw head and the shoulder washer.
- Line up the rear locking hole with the desired adjustment angle hole and install locking screw.
- 5. Tighten all screws.

For Ceiling Suspension: (See Figure 1)

- Suspend the SL15-MB bracket to the ceiling.
  - Caution: Due to the weight of the SL15-2H enclosure, it is imperative that the SL15-MB bracket be secured to the ceiling. The choice of fasteners (not provided with bracket kit) will be determined by the material and construction of the ceiling. It is the responsibility of the Installer to ensure the integrity of the mounting surface.
- Install provided shoulder washer and screw in the easy mounting screw insert position about 3/4 of the way in. Also install the shoulder washer in the appropriate adjustment insert hole.

(See Ceiling Suspension Figure 1)

## SL15-MB Adjustable Mounting Bracket Kit

- Set the SL15-2H on the mounting bracket by sliding the mounting position screws into the easy mounting slot and guiding it into the installed position, which is all the way to the bottom. Make sure the bracket is placed between the screw head and the shoulder washer.
- Line up the top locking hole with the desired adjustment angle hole and install locking screw.
- 5. Tighten all screws.

Figure 1 illustrates how the SL15-2H is positioned on the SL15-MB bracket in the ceiling-suspended position and the wall-mounted position.


#### Uniform Limited Warranty

Electro-Voice products are guaranteed against malfunction due to defects in materials or workmanship for a specified period, as noted in the individual product-line statement(s) below, or in the individual prod-

uct data sheet or owner's manual, beginning with the date of original purchase. If such malfunction occurs during the specified period, the product will be repaired or replaced (at our option) without charge. The product will be returned to the customer prepaid. Exclusions and Limitations: The Limited Warranty does not apply to: (a) exterior finish or appearance; (b) certain specific items described in the individual product-line statement(s) below, or in the individual product data sheet or owner's manual; (c) malfunction resulting from use or operation of the product other than as specified in the product data sheet or owner's manual; (d) malfunction resulting from misuse or abuse of the product; or (e) malfunction occurring at any time after repairs have been made to the product by anyone other than EVI Audio Service or any of its authorized service representatives. Obtaining Warranty Service: To obtain warranty service, a customer must deliver the product, prepaid, to

EVI Audio Service or any of its authorized service representatives together with proof of purchase of the product in the form of a bill of sale or receipted invoice. A list of authorized service representatives is available from EVI Audio Service at 600 Cecil Street. Buchanan, MI 49107 (800/234-6831 or FAX 616/695-4743). Incidental and Consequential Damages Excluded: Product repair or replacement and return to the customer are the only remedies provided to the customer. Electro-Voice shall not be liable for any incidental or consequential damages including, without limitation, injury to persons or property or loss of use. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you. Other Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to

Figure 1-Mounting





### SL15-MB Adjustable Mounting Bracket Kit

Electro-Voice Flying Hardware (including enclosure-mounted hardware and rigging accessories) is guaranteed against malfunction due to defects in materials or workmanship for a period of one (1) year from the date of original purchase. Additional details are included in the Uniform Limited Warranty statement.

For warranty repair, service information, or a listing of the repair facilities nearest you, contact the service repair department at: 616/695-6831 or 800/685-2606.

For technical assistance, contact Technical Support at 800/234-6831 or 616/695-6831, M-F, 8:00 a.m. to 5:00 p.m. Eastern Standard time.

Specifications subject to change without notice.

#### Specifications

#### Mounting Bracket Kit:

Contains one bracket assembly, designed specifically to allow the SL15-2H to be hung from the ceiling or mounted on the wall, four shoulder washers and four 1/4-20 x 1.5 inch hex washers, head screws for securing the SL15-2H

#### Mounting Holes:

Four .280 inch diameter clearance holes, evenly spaced 7.75 inches apart

#### **Enclosure Position feature:**

Three position holes are provided to decrease slippage due to vibration. Provides a 0°, +10° or +20° for alternative aiming angles

#### Speaker Mounting Feature:

The bracket has an easy mounting slot for simpler installations

#### Material:

Cold rolled steel

#### Finish:

Black crinkled paint

#### Net Weight:

2.49 kg (5.5 lb)

#### Shipping Weight:

3.175 kg (7.0 lb)