

## **ProStar R-10, G-10, H-10, B-10 frequency list**

### **Traveling Frequencies:**

065	171.905
066	171.045
068	169.505

### **TV Channel 7**

064	174.075
019	175.000
021	177.800
022	178.400

### **TV Channel 8**

025	183.000
026	183.800
027	184.400