## MODEL 4PM35 AMPLIFIER

A multi-purpose High Fidelity Amplifier designed for use in background music, public address, and high fidelity systems. High gain input for microphone; input for tuner, ceramic or crystal cartridge. Individual controls for each input. Tone control. Pilot light. External fuse receptacle. Separate on-off power switch. Speaker Output Impedances: 4, 8, 16 ohms. Output Lines: 25 volts, 70 volts.

### UNPACKING:

The unit is to be removed carefully from the carton and inspected for any possible damage in transit. If there is any evidence of any damage which might have occurred in shipment, notify your dealer at once, or the transportation company which delivered it. Claims for damage sustained in transit must be made upon the Carrier. Save all packing material for inspection by the claim agent who will furnish you with the proper forms and will also give you the necessary instructions for filing a claim. In addition to the Unit, there should be included in the carton the following:

INSTRUCTION BOOKLET

2. WARRANTY CARD

To insure proper servicing and to protect your rights under the warranty, be sure to fill in the warranty registration card without delay and mail to the factory.

## WARRANTY

This unit has been very carefully inspected and tested at the factory and normally should require no service other than a semi-annual check of the tubes. Each unit is warranted to be free from defects in material and workmanship under normal use and service for a period of 90 days from date of delivery to the original purchaser. If any unit appears to be defective, the factory will repair any unit returned within said 90 days, providing all transportation charges are pre-paid, and which our examination shall disclose to our satisfaction to be defective.

This Warranty does not include free labor, nor is it applicable to any unit which shall have been subject to accident, tampered with, mis-used, abused, or altered in any manner whatsoever. Further, this Warranty shall not apply to any unit which has been connected improperly.

It is recommended that any unit on which service is required, be processed through your dealer wherever possible.

This Warranty is expressly in lieu of all other Warranties, expressed or implied, and of all other obligations or liabilities on our part. We neither assume nor authorize any other person to assume for us any other liability in connection with the products manufactured by Trutone Electronics, Inc.

# INSTALLATION:

Although the amplifier has ample vents for normal ventilation, sufficient space should be allowed around it to permit free air flow.

Do not put books or other objects on top of the Unit, as this would reduce the ventilation and result in reducing the life of the components and tubes.

A special 5 prong socket is provided on the rear of the chassis for connection to RAYMER Model 310 Remote Control Relay, whenever automatic suspension of music during paging is desired.

Plug the AC line cord in any outlet furnishing 105 to 120 volt, 60 cycle AC.

An AC receptacle is located on the rear of the chassis to supply power to other components such as phonograph motor, etc. The auxiliary equipment connected to the AC Receptacle is controlled by the On and Off switch so that turning off the amplifier turns off all equipment.

# TRUTONE ELECTRONICS, INC.

#### CAUTION

The amplifier is provided with a 2 ampere fuse for the protection of the components used in the unit. If the fuse should blow, replace it only with one of identical amperage and under no circumstances with one of greater amperage. If the replacement fuse should blow, replace the 5U4G rectifier tube, which normally will correct the difficulty. If the fuse continues to blow out even with a new rectifier tube, return the amplifier to the factory for warranty repair or replacement.

DO NOT TURN ON THE AMPLIFIER UNTIL THE SPEAKER HAS BEEN CONNECTED TO THE TERMINAL STRIP AS POSSIBLE DAMAGE TO THE EQUIPMENT MAY OCCUR.

