

2-WAY MODE

Electro-Voice Dx-34 DSP Settings

DATE: 7-19-96

AUTHOR: F.D.

TITLE: T252 DX34 SETTINGS

SPEAKER SYSTEM NAME: T252

SOFTWARE VERSION:

PARAMETER		CH 1	CH 2	CH 3	CH 4
MASTER DELAY	2 ms				
MASTER PEQ FREQ	- Hz				
MATER PEQ Q	-				
MASTER PEQ GAIN	0 dB				
LO-CUT FREQ		45 Hz		Hz	
LO-CUT RESP		12 dB 1.5 Q		dB Q	
LOSHELV FREQ		300 Hz		Hz	
LOSHELV SLOPE		12 dB		dB	
LOSHELV GAIN		+5 dB		dB	
HI-PASS FREQ			1200 Hz		Hz
HI-PASS RESP			LINK 24dB		
PEQ1 FREQ		240 Hz	3200 Hz	Hz	Hz
PEQ1 Q		2.5	1.9		
PEQ1 GAIN		+3 dB	-4 dB	dB	dB
PEQ2 FREQ			- Hz		Hz
PEQ2 Q			-		
PEQ2 GAIN			0 dB		dB
LO-PASS FREQ		1200 Hz		Hz	
LO-PASS RESP		LINK 24 dB			
HISHELV FREQ			7400 Hz		Hz
HISHELV SLOPE			6 dB		dB
HISHELV GAIN			+12 dB		dB
DELAY ALIGNM		299 us	0 us	us	us
POLARITY		N.I.	N.I.		
OUTPUT GAIN		0 dB	-5 dB	dB	dB
LIMIT THRESH		21 dBu	21 dBu	dBu	dBu
LIMIT DECAY		50 dB/s	50 dB/s	dB/s	dB/s
LIMIT HOLD		5 ms	5 ms	ms	ms