

2-WAY MODE

DATE: 01-30-95

AUTHOR: Chris Stirling

SOFTWARE

TITLE: T52 + T18

VERSION: V 1.00

SPEAKER SYSTEM NAME: T52 + T18

PARAMETER	INPUT	CH 1	CH 2	CH 3	CH 4
MASTER DELAY		2 ms			
MASTER PEQ FREQ		1000 Hz			
MASTER PEQ Q		1.0			
MASTER PEQ GAIN		0 dB			
LO-CUT FREQ		34 Hz		34 Hz	
LO-CUT RESP		12 dB 0.5 Q		12 dB 0.5 Q	
LOSHLV FREQ			100 Hz		100 Hz
LOSHLV SLOPE			12 dB		12 dB
LOSHLV GAIN			+7 dB		+7 dB
HI-PASS FREQ			164 Hz		164 Hz
HI-PASS RESP			4th BW		4th BW
PEQ1 FREQ	80 Hz	2500 Hz	80 Hz	2500 Hz	
PEQ1 Q	1.0	1.0	1.0	1.0	
PEQ1 GAIN	0 dB	0 dB	0 dB	0 dB	
PEQ2 FREQ		16000 Hz		16000 Hz	
PEQ2 Q		1.0		1.0	
PEQ2 GAIN		0 dB		0 dB	
LO-PASS FREQ	164 Hz		164 Hz		
LO-PASS RESP	2nd LW		2nd LW		
HISHLV FREQ		10000 Hz		10000 Hz	
HISHLV SLOPE			6 dB		6 dB
HISHLV GAIN		0 dB		0 dB	
DELAY ALIGNM		0 us	2069 us	0 us	2069 us
POLARITY	+	+	+	+	
OUTPUT GAIN	0 dB	0 dB	0 dB	0 dB	
LIMIT THRESH	21 dBu	21 dBu	21 dBu	21 dBu	
LIMIT DECAY	50 dB/s	50 dB/s	50 dB/s	50 dB/s	
LIMIT HOLD	0 ms	0 ms	0 ms	0 ms	